

Fab Pole™



L'Ru Studios LLC

Nexus Wrap™ + Sling System™ by FabPole™

The Sling System™ uses a combination of climbing, mountaineering equipment and the Nexus Wrap™ to attach aerial fabric to a vertical pole or other apparatuses.

FabPole™ and L'Ru Studios LLC company disclaimer and customer warning:

FabPole™, vertical pole, acrobatics, aerial dance and fitness are dangerous and strenuous activities and involve the risk of physical injury and/or death. **You understand that you may sustain physical injury and/or death while engaging in such activities and that you should check with your physician before engaging in these activities.** The purchaser and/or user of the Nexus Wrap™ with Sling System™ and FabPole fabric for any or a combination of activities above understands the risk and agrees that L'Ru Studios, LLC and/or its officers, directors, members, employees, trainers, coaches, instructors, agents, and lessors collectively are not liable for any physical injury and/or death caused during these activities. By purchasing or using aerial equipment, including, but not limited to, vertical poles, fabric, carabiners, swivels, slings, runners, daisy chains and any other forms of equipment, the purchaser or user agrees that FabPole™ and L'Ru Studios LLC is not liable for any damage, injury, or death caused during the use of aerial equipment and/or aerial dance, acrobatics activities and/or any other activities or equipment. FabPole™ and L'Ru Studios LLC advise that you consult and/or hire a professional aerial coach for instruction. It is recommended that a professional rigger be hired for installation of these and all aerial apparatus. FabPole™ fabric/silks should only be used for FabPole activities and dance. You should never use this product for aerial dance or acrobatics.

THE USE OF THESE PRODUCTS AND PROCEDURES IS DOING SO AT YOUR OWN RISK.

Helpful tips:

- Instruction video to shorten FabPole fabric without cutting. www.fabpole.net
- Make sure large nylon sling strap installed in Step Two are not twisted and NOT on the hook and loop attachment pieces of the Nexus Wrap™.
- The ring may leave a mark on light colored fabrics.
- Washing and drying fabric - use powder detergent without fabric softeners, gentle wash cycle, cold water. Untangle before putting in dryer, dry on low until almost dry, remove and untangle.
- Clean your Nexus Wrap with alcohol, water or soap and water.

**Nexus Wrap™ with Sling System™ instructions -
Instruction video online www.fabpole.net/shop -**

Included: Nexus Wrap™, large Nylon sling, ring, carabiner.



Step One: If you are using the Nexus Wrap™, wrap it securely around the pole and secure the hook and loop straps at your preferred height.



Step Two: Use a Girth Hitch to attach the large Nylon sling to your bolt or Nexus Wrap™.

***Tighten to ensure security.**

***The sling must be on the Nexus Wrap™ NOT on the hook and loop.**



Step Three: Fold the fabric in half.
Insert the folded/loop end of the fabric through the ring.



Step Four: Wrap the top loop over the ring and pull the ring through the top of the loop. Pull tight to secure.



Step Five: Attach the carabiner to the loop or ring created in Step Four.



Step Six: Attach the carabiner to the ring or large Nylon sling installed in Step Two.

***Tighten to ensure security.**

***The sling must be on the Nexus Wrap™ NOT on the hook and loop.**



Step Seven: Apply your weight or a good tug downward to the fabric to ensure the attachments are secure. Periodically check for damage and that the Sling System™ and Nexus Wrap™ are secure.

www.FabPole.net
www.LRuStudios.com
303-523-3703